

Hygenall™ **HEXOFF™** Surface Cleaner

Instructions for use.

USAGE: use to clean and decontaminate surfaces after exposure to heavy metals including Hexavalent Chromium and Cadmium. CM3033



PN: HXLS9001Q

These instructions should be considered as general usage guidance, and may need to be adjusted through experimentation for varying types of surfaces and contamination levels.

5 Gallon (PN: HXLS9005G) and 55 Gallon (PN: HXLS90055G) versions are concentrated, and depending on the amount of Cr(VI) contamination, and type of surface, the formula may be diluted up to 4 parts water to 1 part Hygenall surface solution. As noted above, it is important to experiment and test to achieve



Safety First

Please follow all directions and warnings on the label, including wearing appropriate safety equipment. Test surfaces in an inconspicuous area to ensure compatibility. **KEEP OUT OF THE REACH OF CHILDREN.**

Light Dirt and Contamination

Apply generously, wait 5 to 10 seconds, wipe off with damp towel. Avoid letting formula dry on surface.

Heavy Dirt and Contamination

Spray on surface and let sit for 30 to 60 seconds (with hexavalent chromium, let sit up to 4 minutes).

Avoid allowing formulation to dry on the surface by applying generous amounts.

Scrub with brush or scrubbing pad, rinse with fresh water or wipe surface with a heavily wetted towel.

Repeat as necessary.

Follow an established cleaning schedule using Hygenall cleaning and decontamination products to keep contaminants from accumulating.

If over used, use a damp towel to clean off excess or dried soap on surface.